ASSEMBLY INSTRUCTION

DESCRIPTION

4055WHT

Opera Coffee Table


1.5 hr


APPROXIMATE ASSEMBLY TIME


2 PERSON ASSEMBLY

FLOORAREA
2MX1.6M

REQUIRED ASSEMBLY SOACE








REQUIRED ASSEMBLY TOOLS

ASSEMBLED DIMENSIONS



ASSEMBLY INSTRUCTION

DESCRIPTION

4055WHT

Opera Coffee Table

WARNING : ENSURE THE WALL STRAP IS ATTACHED TO AVOID SERIOUS INJURY OR DEATH.

To avoid any serious or fatal injury, a wall strap has been provided with this product to prevent toppling. Always secure this product with an anchor device to the wall or suitable surface. Wall fixing hardware are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

Your product has been provided with a permanent safety label that should never be removed for safety reasons.




ASSEMBLY INSTRUCTION

DESCRIPTION

4055WHT

Opera Coffee Table

PARTS LIST



NO.	PARTS LIST	QTY
(1)	Part1	2
(2)	Part2	2
(3)	Part3	2
(4)	Part4	1
(5)	Parts	1
(6)	Part6	1
(7)	Part7	2
(8)	Part8	2
(9)	Part9	1


ASSEMBLY INSTRUCTION

DESCRIPTION


4055WHT

Opera Coffee Table

HARDWARE LIST




50X	50X	18X	36X
M7.5m/m	Dia:15x11.5m/m	Dia:8x30m/m	Dia:4x10m/m
A	**B**	**C**	**D**
CAM-BOLT	CAM-LOCK	WOOD DOWEL	WOOD SCREW



1X


E

GLUE



2X

F



2X

G

ASSEMBLY INSTRUCTION

DESCRIPTION

4055WHT

Opera Coffee Table

Top Tips before you start!

1. Please check that all parts are present before you start the assembly of your furniture, as once assembled, the furniture is exempt from our home approval policy.

2. For ease and speed of assembly, we recommend that before you commence each step of the assembly, that you identify all the parts required for that step.

3. For larger items,please ensure that you have sufficient space and people(as indicated on page 1) to assemble your product safely.

4. We recommend that.where possible,all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.

5. For the protection of your fumiture,partirularly items of high gloss finish, we recommend that the product is placed on a protected surface during assembly to prevent any damage.

6. During assembly please take care not to over-tighten any fittings,as this may damage the product.

Care and Maintenance of your Furniture

- Please periodically check all fittings and re-tighten as necessary.
- Please do not drag or pull your furniture.
- Wipe occasionally with a soft cloth slightly dampened with water.Then buff with a dry clean soft cloth.
- Never allow any kind of liquid to remain on your furniture.Absorption can cause wood to warp or finishes to de-laminate.
- Please do not sit or stand on this item.

ASSEMBLY INSTRUCTION

DESCRIPTION


4055WHT

Opera Coffee Table

STEP 1


SPECIAL TIPS FOR FITTING CAM-LOCKS AND CAM-BOLTS

CAM-LOCK




WHEN FITTING CAMS

ENSURE STARTING POSmON 15 CORRECT
BEFORE YOU INSERT CONNECTING CAM-BOLTS
TURN CLOCKWISE UNTIL SECURE




Align with long point of cross





Lock head needs to be in centre

CAM-BOLT

Tighten until shoulder is flush with panel.Do not overtighten or undertighten (see example below)








ASSEMBLY INSTRUCTION


DESCRIPTION

4055WHT

Opera Coffee Table

STEP 2





4X
A

2X
C


ASSEMBLY INSTRUCTION


DESCRIPTION

4055WHT


Opera Coffee Table

STEP 3





10X
A



12X
C


ASSEMBLY INSTRUCTION


DESCRIPTION

4055WHT

Opera Coffee Table

STEP 4





4X
B


ASSEMBLY INSTRUCTION

DESCRIPTION


4055WHT

Opera Coffee Table

STEP 5



x2



24X
A

4X
C


ASSEMBLY INSTRUCTION


DESCRIPTION

4055WHT

Opera Coffee Table

STEP 6





8X
B


ASSEMBLY INSTRUCTION


DESCRIPTION

4055WHT

Opera Coffee Table

STEP 7





4X
B


ASSEMBLY INSTRUCTION

DESCRIPTION


4055WHT

Opera Coffee Table

STEP 8



x2



12X
A


ASSEMBLY INSTRUCTION


DESCRIPTION

4055WHT

Opera Coffee Table

STEP 9





4X
B


ASSEMBLY INSTRUCTION


DESCRIPTION

4055WHT

Opera Coffee Table

STEP 10





8X
B


ASSEMBLY INSTRUCTION


DESCRIPTION

4055WHT

Opera Coffee Table

STEP 11





10X
B


ASSEMBLY INSTRUCTION


DESCRIPTION

4055WHT

Opera Coffee Table

STEP 12





12X
B


ASSEMBLY INSTRUCTION

DESCRIPTION

4055WHT

Opera Coffee Table


STEP 13




x2



12X
D



2X
F



2X
G


ASSEMBLY INSTRUCTION


DESCRIPTION

4055WHT

Opera Coffee Table

STEP 14





12X
D


ASSEMBLY INSTRUCTION


DESCRIPTION

4055WHT

Opera Coffee Table

STEP 15





12X
D

ASSEMBLY INSTRUCTION

DESCRIPTION

4055WHT

Opera Coffee Table

STEP 16

